

HPT302 UDMA/ATA133 Controller

Caldera OpenLinux 2.3 / 2.4

Installation Guide

Version 1.0

Copyright © 2001 HighPoint Technologies, Inc.

All rights reserved.

Last updated on Jan 7, 2002

Table of Contents

| | |
|---|----------|
| 1 Overview..... | 1 |
| 2 Installing OpenLinux on HPT302 Controller | 1 |
| Step 1 Prepare Your Hardware for Installation | 1 |
| Step 2 Check System BIOS Settings..... | 1 |
| Step 3 Prepare the Boot Diskette..... | 1 |
| Step 4 Install Caldera OpenLinux..... | 2 |
| 3 Installing HPT302 Driver on an Existing System..... | 2 |
| Step 1 Obtain the Driver Module..... | 2 |
| Step 2 Test the Driver Module | 3 |
| Step 3 Configure System to Automatically Load the Driver..... | 3 |
| Step 4 Configure System to Mount Volumes when Startup | 4 |
| 4 Monitoring the Driver..... | 4 |
| Checking Devices Status..... | 5 |
| 5 Updating the Driver..... | 5 |
| 6 Uninstalling..... | 5 |
| Uninstalling the Driver..... | 5 |

1 Overview

The purpose of this document is to provide clear instructions on how to install and use HPT302 UDMA/ATA133 Controller on Caldera OpenLinux system.

2 Installing OpenLinux on HPT302 Controller

If you would like to install Caldera OpenLinux onto drives attached to HPT302 controller, please perform the following operations:

Step 1 Prepare Your Hardware for Installation

After you attach your hard disks to HPT302 controller, you can use HPT302 BIOS Setting Utility to configure your hard disks. You can select a hard disk as boot disk, otherwise HPT302 BIOS will automatically select the first one attached as boot disk.

Before installation, you must remove all the disk drives, which are not physically attached to HPT302 controller, from your system.

Note

If you have other SCSI adapters installed, you must make sure the HPT302 controller BIOS will be loaded firstly. If not, try to move it to another PCI slot. Otherwise you may be unable to boot up your system.

Step 2 Check System BIOS Settings

In your system BIOS SETUP menu, change **Boot Sequence** in such a way that the system will first boot from floppy or CDROM, and then from SCSI. Refer to your BIOS manual to see how to set boot sequence.

If your BIOS settings do not support such a boot sequence, you can first set it to boot from floppy or CDROM. After you finish installation, set SCSI as the first boot device to boot up the system.

Step 3 Prepare the Boot Diskette

To install Caldera OpenLinux onto HPT302 controller, you must boot from a customized boot diskette to start installation.

First obtain the boot diskette image file, col23boot.img or col24boot.img. If you are installing Caldera OpenLinux 2.3, you should use col23boot.img. If you are installing Caldera OpenLinux 2.4, you should use col24boot.img.

On a DOS or Windows system, you can make the boot diskette using rawrite.exe. It can be found on the Caldera OpenLinux CD (under /dosutils). Just run it under a command window and follow its prompt. (Note: rawrite.exe can only read 8.3 file name format, so

the file name “col23boot.img” should be typed as “col23b~1.img”).

On a Linux system, you can use the “dd” command to make the boot diskette. Insert a floppy disk into the floppy drive and type the command:

```
# dd if=col23boot.img of=/dev/fd0
```

Step 4 Install Caldera OpenLinux

- 1) Start installing the Caldera OpenLinux by booting from the bootable disk provided for HPT302 driver.
- 2) When a prompted label “**boot:**” appears, press “**enter**”.
- 3) The hpt302 module will be automatically loaded. You can simply continue the installation as normal. Please refer to Caldera OpenLinux installation guide.

Note

The system device mapping order is the same as the order shown in HPT302 BIOS Setting Utility. If you have no other SCSI adapters installed, the device marked as “BOOT” or “HDD0” will be /dev/sda, “HDD1” will be /dev/sdb, “HDD2” will be /dev/sdc, etc. When creating mount points, you must mount /boot on /dev/sda.

- 4) When the “Setup Boot Loader” screen appears, you must select “write master boot record (MBR)” option to make the system able to boot up from your HPT302 controller.

3 Installing HPT302 Driver on an Existing System

If you are currently running Linux and would like to access drives or arrays attached to the HPT302 Controller, you can perform the following steps.

Note

If you use a SCSI adapter to boot your system, you must make sure the HPT302 controller BIOS will be loaded after that adapter’s BIOS. If not, try to move it to another PCI slot. Otherwise you may be unable to boot up your system.

Step 1 Obtain the Driver Module

You can extract the module file from the boot diskette provided. Insert the boot diskette into floppy drive and type the following commands:

```
# mount /dev/fd0
# gzip -dc /mnt/floppy/initrd.gz > /tmp/initrd.ext2
# mkdir /mnt/initrd
# mount -o loop /tmp/initrd.ext2 /mnt/initrd
# cp /mnt/initrd/lib/modules/2.2.14/scsi/hpt302.o /tmp
# umount /mnt/initrd
```

The driver module, hpt302.o, will be copied to /tmp for your use.

Step 2 Test the Driver Module

You can test out the module to ensure that it works for your system by typing in **"insmod hpt302.o"**.

Sometimes insmod will report **"unresolved symbols"** when you attempt to load the module. This can be caused by two ways:

1) If your system is using a kernel which has not built-in SCSI support, you must load the SCSI module before load hpt302.o. Try to load SCSI modules first.

E.g.

```
# insmod scsi_mod
# insmod sd_mod
# insmod hpt302.o
```

2) If you recompile the kernel with SCSI support and still receive the **"unresolved symbols"** error, it may be caused that you have not configured symbol versioning correctly. To correct it, recompile the kernel with symbol versioning configured. Please refer to the kernel documents for more information.

If the module has been loaded successfully you should see the HPT302 banner and a display screen of the attached drives. You can now access the drives as a SCSI device (the first device is /dev/sda, then /dev/sdb, etc.).

Example

If you have one disk attached to HPT302, it will be registered to system as device **/dev/sda**. You can use **"fdisk /dev/sda"** to create a partition on it, which will be **/dev/sda1**, and use **"mkfs /dev/sda1"** to setup a file system on the partition. Then you can mount **/dev/sda1** to somewhere to access it.

Step 3 Configure System to Automatically Load the Driver

Most likely, you will not want to type in **"insmod hpt302.o"** each time you boot up the system. Therefore you must install the module and tell the system about it. To install the module, type in the following commands (first change directory to where the proper hpt302.o can be located):

```
# install -d /lib/modules/2.2.14/scsi
# install -c hpt302.o /lib/modules/2.2.14/scsi
```

Then you should inform the system when to load the module.

1. If you have no other SCSI adapters installed, you can edit the file **"/etc/modules.conf"** and add the following lines:

```
alias block-major-8 hpt302
pre-install hpt302 modprobe sd_mod
```

options -k hpt302

This tells the kernel to try loading the SCSI and hpt302 modules whenever it tries to access a SCSI device /dev/sd[a-z]. If you have SCSI support compiled in kernel, you may remove the line “**pre-install hpt302 ...**”.

The line “options -k hpt302” ensures the module will not be autocleaned.

Notice

Upon your system configuration the modules configuration file may be another file, possibly deprecated "conf.modules" file. You may have to check which configuration file you use and modify the correct one.

Now, reboot the system and try to type in the command "fdisk /dev/sda". The kernel should automatically load the hpt302 driver.

2. If you use a SCSI adapter to boot the system, you cannot do as above since this may conflict with other SCSI devices. However, you can add the driver to the existing RAM disk image. First check which image file you are using by checking the “initrd=” line in file /etc/lilo.conf, then use the following commands (we assume the file is /boot/initrd-2.2.14.gz):

```
# gzip -dc /boot/initrd-2.2.14.gz > /tmp/initrd.ext2
# mkdir /mnt/initrd
# mount -o loop /tmp/initrd.ext2 /mnt/initrd
# cp hpt3702.o /mnt/initrd/linux/modules (specify the correct location of
hpt302.o here)
# echo “hpt302” >> /mnt/initrd/etc/modules/rootfs
# umount /mnt/initrd
# gzip -c /tmp/initrd.ext2 > /boot/initrd-2.2.14.gz
# lilo
```

Then reboot your system and the driver will be loaded.

Step 4 Configure System to Mount Volumes when Startup

Now you can inform the system to automatically mount the array by modifying the file /etc/fstab. E.g. You can add the following line to tell the system to mount /dev/sda1 to location /mnt/hpt after startup:

```
/dev/sda1      /mnt/hpt      ext2    defaults    0 0
```

4 Monitoring the Driver

Once the driver is running, you can monitor it through the Linux proc file system support. There is a special file under /proc/scsi/hpt302/. Through this file you can view driver status and send control commands to the driver.

Note

The file name is the SCSI host number allocated by OS. If you have no other SCSI cards installed, it will be 0. In the following sections, we will use X to represent this number.

Checking Devices Status

Using the following command to show driver status:

```
# cat /proc/scsi/hpt302/X
```

This command will show the driver version number, physical device list and logical device list.

5 Updating the Driver

If you are not booting from disks attached to HPT302 controller, you can update the driver just by reinstalling it following the previous section, **"Install driver to an existing system"**.

If you are using a system installed to HPT302 controller, you can update the driver by the following steps.

1) First obtain the new driver module file hpt302.o. Refer to the previous section **"Obtain the driver module"**. In the following steps, we assume you have copied it to /tmp/hpt302.o.

2) Replace hpt302.o in the boot RAM disk image by using the following commands:

```
# gzip -dc /boot/initrd-2.2.14.gz > /tmp/initrd.ext2
# mkdir /mnt/initrd
# mount -o loop /tmp/initrd.ext2 /mnt/initrd
# cp /tmp/hpt302.o /mnt/initrd/linux/modules/
# umount /mnt/initrd
# gzip -c /tmp/initrd.ext2 > /boot/initrd-2.2.14.gz
```

3) Use "lilo" to reinstall the RAM disk:

```
# lilo
```

4) Update the hpt302.o in /lib/modules:

```
# cp /tmp/hpt302.o /lib/modules/2.2.14/scsi/hpt302.o
```

5) Reboot your system to make the new driver take effect.

6 Uninstalling

Uninstalling the Driver

You can only uninstall the driver when your system is not booting from devices attached to HPT302 controller. Just remove the lines you added to /etc/modules.conf and /etc/fstab.